Elevator Cab Air Disinfection Purifier

Wall Installation

Air Disinfection Purifier unit comes with 3M self-adhesive backside tape and keyhole mount for installation.

- **1.** Mark the mounting hole center on the cabin wall. Distance of 6" or more below the top of the cabin is recommended, but no less than 3.5". It reserves room for top wiring, operation and service.
- 2. Drill the hole for 3/16" or smaller keyhole screw.
- **3.** Insert the screw into the hole. Leave 1/8" gap from screw head to the wall.
- **4.** Use keyhole to hang the purifier. Align the unit and mark its position with a pencil.
- **5.** Remove the purifier. Tear off 3M tape protection film from backside of the unit.
- **6.** Reinstall purifier according to the position marks and apply pressure to self-adhesive tape. Tighten keyhole screw. Remove pencil marks.
- **7.** Connect power adapter 24VDC plug to purifier. Plug the adapter power cord into 120VAC power source.





